


YUSPHONE WIRING DIAGRAM

(YUS180-DFC2/DFN2/DFC4/DFN4)

(YUS180-DCC1/DCN1/DCC4/DCN4)



1. Every 4 Video room stations require 1pc of YUS180-SP1. Otherwise, 8 audio room stations require 1pc of SP1.
2. Room station connection of F1, F2, F3, F4 must connected with VSS while they are not connected with any security detector.
3. Main wire using 5V2V coaxial cable , sub-wire using 3C2V coaxial cable.
4. Please provide extra power for lock release.

F1	Security 1	EXIG2	SOS 2
F2	Security 2	AON	Alarm on
F3	Security 3	AONL	Alarm light
F4	Security 4	BELL	Bell
GAS	Gas	RLY+	Relay +
VSS	Grand wire	RLY-	Relay -
AOUT	Audio	COM	Commend
EXIG1	SOS 1	NO	Normal open

