






YUSPHONE WIRING DIAGRAM TU1-8F



P.S. 1. This system can page and communicate with maximums 8 stations.

2. No.1 station plug jump wire to (room set) 1, No.2 station plug jump wire to (room set) 2 and so on..